




Wir schaffen Wissen – heute für morgen

Paul Scherrer Institut


Joachim Reimer


Biomass related Salt Solutions at Hydrothermal Conditions



Background – Gasification of Wet Biomass

Continuous salt separation is part of the PSI process of hydrothermal gasification of wet biomass to synthetic natural gas (SNG) in supercritical water.






Challenges:


- precipitation of solid salt leads to blocking of the apparatus
- sulfur species poison the methanation catalyst
- phosphorus and potassium are valuable components, which could be re-used as fertilizer in biomass production

An effective salt separation and recovery is the crucial issue in the hydrothermal gasification process!


Introduction – Properties of Water at elevated p and T



Source: NIST Chemistry Webbook



Source: NIST Chemistry Webbook




- The dielectric constant of water becomes similar to those of typical organic solvents at high pressures and temperatures.
- Increased solubility of organic substances

Taken from M.Uematsu & E.U. Franck, J. Chem. Phys. Ref. Data, Vol. 9, No. 4, 1980.

Type 1d:


- Continuous solubility line (G-L-S) from triple point of water to triple point of salt
- Liquid immiscibility starts at lower critical point N
- At upper critical point R the dilute liquid solution and the gas phase become equal
- Solutions $\text{Na}_2\text{HPO}_4\text{-H}_2\text{O}$, $\text{K}_2\text{HPO}_4\text{-H}_2\text{O}$



Adapted from: V. M. Valyashko, Phase equilibria in binary and ternary hydrothermal systems, in Hydrothermal Experimental Data, pages 1–133, John Wiley & Sons, Ltd, 2008.

Type 2d':


- Discontinuous solubility line (G-L-S)
- Intersection of solubility line (G-L-S) with vapor-liquid critical line in the lower critical end point p respectively in the upper critical end point q.
- Between p and q either a one phase fluid or a fluid in equilibrium with solid exists.
- Metastable liquid immiscibility which 'bridges' the gap between the critical endpoints p and q
- Solutions $\text{Na}_2\text{SO}_4\text{-H}_2\text{O}$, $\text{K}_2\text{SO}_4\text{-H}_2\text{O}$




Adapted from: V. M. Valyashko, Phase equilibria in binary and ternary hydrothermal systems, in Hydrothermal Experimental Data, pages 1–133, John Wiley & Sons, Ltd, 2008.

- Setaram Sensys DSC with Calvet-sensor
- Incoloy®-crucibles suitable up to 600° C/500 bar
- nominal inner volume: 130 μL
- volume as determined: 128.63 μL
- heating rate 0.1 K/min or 0.05 K/min
- carrier gas 20 mL/min Argon
- measurement interval 300-400° C
- 3 cycles with 1h stabilization period prior to measurement
- sample weight: 38.6 mg corresponding to 300 kg/m³ overall density








J.Reimer, F.Vogel, RSC Adv., 2013,3, 24503-24508.

Heat flow curves in the cooling mode



- Limited to small sample mass (mg range) therefore small signals at low heating/cooling rates

$$\Phi_{measured} = \Phi_{sample} + \Phi_{baseline} = c_v \cdot m \cdot \beta + \Phi_{baseline}$$

- High deviations in heat flow curves and measured baselines → big error in C_v
- Error in onset-temperatures of the phase transitions on repetition is smaller than 0.3°C


$$\rho_{vap}V_{vap} + \rho_{liq}(V - V_{vap}) = M \quad \Leftrightarrow \quad (1)$$


Density data from literature needed!


$$V_{vap} = \frac{\rho_{liq}V - M}{\rho_{liq} - \rho_{vap}} \quad (2)$$

$$\frac{x_{liq}}{100 \text{ wt.}\%} = \frac{M_{salt}}{\rho_{liq}V_{liq}} = \frac{M_{salt}}{\rho_{liq}(V - V_{vap})} \quad (3)$$


Adapted from: Valyashko *et al.*, J. Chem. Eng. Data, **2000**, 45, 1139-1149.








Comparison $K_2HPO_4 \cdot H_2O$ and $Na_2SO_4 \cdot K_2SO_4 \cdot H_2O$




J.Reimer, F.Vogel, RSC Adv., 2013,3, 24503-24508.

The Sapphire Cell

- A high temperature and pressure cell that allows the phase behaviour of salt solutions to be visually observed.



The Sapphire Cell



Summary...

- DSC is a good tool to investigate phase transitions qualitatively and if phase density data is available also quantitatively.
- Corresponding vapor pressures need to be measured separately.
- Higher mixtures of salts can exhibit a totally different phase behavior compared to binary mixtures.
- The measured data yields a deeper insight into the salt separation process and offers the opportunity to improve the salt separation.



Many thanks to ...

F. Vogel, E. De Boni, S. Pin, T. Huthwelker, M. Gorman, T. Driesner (ETHZ), M. Steele-MacInnis (ETHZ) and A. Wokaun.

Swiss National Science Foundation (SNF) for financial support

