



# Ultrafast Laser Physics


Ursula Keller / Lukas Gallmann

*ETH Zurich, Physics Department, Switzerland*  
[www.ulp.ethz.ch](http://www.ulp.ethz.ch)


*Chapter 5: Relaxation oscillations in lasers*





## Longitudinal pumping




## Transversal pumping



# Diode-pumped solid-state lasers




## Three-level system




## Four-level system

Nd-doped  
Ti:sapphire



# Laser rate equation



- ideal four-level system
- single mode laser
- homogeneous broadened gain material

$N$  inversion  $N = N_2 - N_1$ ,  $N_1 \approx 0$

$n$  photon number (intracavity)

$W^{stim} \equiv W_{12} = W_{21} = Kn$

$KN$  spontaneous emission rate

$KnN$  stimulated emission rate

$\gamma_c$  cavity photon decay rate

$\gamma_L$  spontaneous decay rate of level 2


$$\frac{dn}{dt} = K(n + 1)N - \gamma_c n$$

$$\frac{dN}{dt} = R_p - KnN - \gamma_L N$$

# Steady-state solution


Above threshold, i.e.  $r > 1$

$$\Leftrightarrow \begin{cases} n_s \approx \frac{\tau_c}{\tau_L} N_{th}(r - 1) = \frac{\gamma_L}{K}(r - 1) \\ N_s \approx N_{th} = \frac{\gamma_c}{K} \end{cases}$$



Below threshold, i.e.  $r < 1$

$$\Leftrightarrow \begin{cases} n_s = \frac{r}{1-r} \\ N_s \approx r N_{th} \end{cases}$$



# Linearized rate equations

$$\begin{aligned} n(t) &= n_s + n_1(t), \quad n_1(t) \ll n_s \\ N(t) &= N_s + N_1(t), \quad N_1(t) \ll N_s \end{aligned}$$

$$\frac{dn_s}{dt} = 0, \quad \frac{dN_s}{dt} = 0$$

$$\frac{dn_1(t)}{dt} = \gamma_L(r - 1)N_1(t)$$

Solution: Ansatz

$$n_1(t) \propto e^{st}, \quad N_1(t) \propto e^{st}$$

$$\frac{dN_1(t)}{dt} = -\gamma_L r N_1(t) - \gamma_c n_1(t)$$

$$s = s_{1,2} = -\frac{r\gamma_L}{2} \pm \sqrt{\left(\frac{r\gamma_L}{2}\right)^2 - \gamma_L\gamma_c(r - 1)}$$



# Over-critical damping (no relaxation oscillations)

$$\begin{aligned} n(t) &= n_s + n_1(t), \quad n_1(t) \ll n_s \\ N(t) &= N_s + N_1(t), \quad N_1(t) \ll N_s \end{aligned}$$

Solution: Ansatz

$$n_1(t) \propto e^{st}, \quad N_1(t) \propto e^{st}$$

$$s = s_{1,2} = -\frac{r\gamma_L}{2} \pm \sqrt{\left(\frac{r\gamma_L}{2}\right)^2 - \gamma_L\gamma_c(r-1)}$$

s is real and negative:  $\left(\frac{r\gamma_L}{2}\right)^2 > \gamma_L\gamma_c(r-1)$

two solutions: two over-critically damped relaxation constants:

$$r\gamma_L \gg \gamma_c \quad \Rightarrow \quad \begin{cases} s_1 = -r\gamma_L & \text{Stimulated decay rate of excited atoms} \\ s_2 = -\gamma_c \frac{r-1}{r} & \text{Photon decay rate inside laser cavity} \end{cases}$$

$$s_2 = -\gamma_c \frac{r-1}{r} \quad \Rightarrow \quad s_2 \approx -\gamma_c, \quad \text{for } r \gg 1$$

# Over-critical damping (no relaxation oscillations)

Example HeNe Laser (p. 200)

$\lambda = 632.8 \text{ nm}$ ,  $\tau_L \approx 100 \text{ ns}$ ,  $2l = 0.02$  (2% output coupler),  
 $T_R = 2 \text{ ns}$

$$\Rightarrow \tau_c = \frac{T_R}{2l} \approx 100 \text{ ns} \Rightarrow \tau_L \approx \tau_c, \quad \text{or} \quad \gamma_L \approx \gamma_c$$

For  $r \gg 1$  (when HeNe is pumped sufficiently far above threshold)  
condition for over-critical damping is fulfilled:

$$r\gamma_L \gg \gamma_c$$

HeNe laser falls back into steady state after about 100 ns

$$\begin{aligned} n(t) &= n_s + n_1(t), \quad n_1(t) \ll n_s \\ N(t) &= N_s + N_1(t), \quad N_1(t) \ll N_s \end{aligned}$$

Solution: Ansatz

$$n_1(t) \propto e^{st}, \quad N_1(t) \propto e^{st}$$

$$s = s_{1,2} = -\frac{r\gamma_L}{2} \pm \sqrt{\left(\frac{r\gamma_L}{2}\right)^2 - \gamma_L\gamma_c(r-1)}$$

s is complex:  $\left(\frac{r\gamma_L}{2}\right)^2 < \gamma_L\gamma_c(r-1)$



relaxation oscillations with an attenuation factor:

$$n(t) = n_s + n_1 e^{-\gamma_{relax} t} \cos(\omega_{relax} t)$$

$$\gamma_{relax} = \frac{r\gamma_L}{2}$$

$$\gamma_c \gg r\gamma_L : \quad \omega_{relax} \approx \sqrt{\frac{r-1}{\tau_L} \frac{1}{\tau_c}} = \sqrt{\frac{1}{\tau_{stim}} \frac{1}{\tau_c}}$$

# Relaxation oscillations



Relaxation oscillations in the time domain and frequency domain  
(microwave spectrum analyzer - not optical frequencies!)



$$n(t) = n_s + n_1 e^{-\gamma_{relax} t} \cos(\omega_{relax} t)$$

$$\gamma_{relax} = \frac{r\gamma_L}{2}$$


$$\gamma_c \gg r\gamma_L : \quad \omega_{relax} \approx \sqrt{\frac{r-1}{\tau_L} \frac{1}{\tau_c}} = \sqrt{\frac{1}{\tau_{stim}} \frac{1}{\tau_c}}$$

# Relaxation oscillations

Example:  
diode-pumped cw Nd:YLF laser



# Measurement of small signal gain



$$g = \frac{g_0}{1 + 2I/I_{sat}}$$

$$f_{relax} \approx \frac{1}{2\pi} \sqrt{\gamma_L \gamma_c (r - 1)} = \frac{1}{2\pi} \sqrt{\frac{r - 1}{\tau_L \tau_c}} = \frac{1}{2\pi} \sqrt{\frac{\frac{g_0}{l} - 1}{\tau_L \frac{T_R}{2l}}} = \frac{1}{2\pi} \sqrt{\frac{2g_0 - 2l}{\tau_L T_R}}$$

$$\tau_c = \frac{T_R}{2l}$$

$$2g_0 \approx 4\pi^2 \tau_L T_R f_{relax}^2 + 2l$$

$$r = \frac{g_0}{l}$$

$$G_0 \approx e^{2g_0} = \exp(4\pi^2 \tau_L T_R f_{relax}^2 + 2l)$$

# Measurement of small signal gain

Measured relaxation oscillation frequency for different output couplers, for  $g_0 \gg l$

$$f_{relax} \approx \frac{1}{2\pi} \sqrt{\frac{2g_0 - 2l}{\tau_L T_R}} \xrightarrow{g_0 \gg l} \approx \frac{1}{2\pi} \sqrt{\frac{2g_0}{\tau_L T_R}}$$

relaxation oscillations independent of output coupler

$$2g_0 \approx 4\pi^2 \tau_L T_R f_{relax}^2 + 2l$$

$$G_0 \approx e^{2g_0} = \exp(4\pi^2 \tau_L T_R f_{relax}^2 + 2l)$$

Example: diode-pumped Nd:YLF laser

